

# Clinipine

## CONCENTRATED PINE, PHENOLIC BASED CLEANER AND DISINFECTANT

### DESCRIPTION

Clinipine is a pine disinfectant that contains substituted phenolics, wetting agents, and emulsifiers. The pure pine oil provides a long lasting pleasant fragrance.

### APPLICATIONS (Usage Areas)

Clinipine is used for general purpose, disinfecting, cleaning and deodorizing of toilet areas, urinals, wards, sani-bins, bathrooms, basins and refuse areas. Clinipine can be safely used in mortuaries, hospitals, nursing homes, old age homes and the hospitality industry where clean and hygienic conditions are essential. Clinipine is a recommended as a disinfectant for use in hospital laundries. (sluicing).

### DIRECTIONS FOR USE

Dilute 40 ml of Clinipine to 1 liter of water. Allow 5 minutes contact time before rinsing. Pre-clean heavily soiled surfaces with neutral detergent.

### BENEFITS

Broad spectrum efficacy  
High level of germicidal activity  
Hot and cold applications  
Suitable in hard and soft water  
Non volatile, non corrosive

### PRECAUTIONS

Clinipine contains sub. phenolics.

- Do not use with other detergents
- Avoid direct contact with eyes and skin
- Wear impervious rubber gloves
- Do not ingest product
- Keep out of the reach of children

### EMERGENCY TREATMENT

Skin contact: Flush immediately with soap and water, wash contaminated clothing before reuse. If irritation develops, seek medical advice.

Eye contact: Rinse immediately with plenty of water for 15 minutes with eyelids held wide open. Seek medical advice.

Inhalation: Move person to fresh air and seek medical advice.

Ingestion: Do not induce vomiting. Give 2 glasses of water to drink and seek immediate medical attention.

### STORAGE

Clinipine has a shelf life of two years. Once dispensed use immediately.

Conditions to avoid:

Temperatures above 30C

Avoid direct sunlight

Incompatible materials:

Acids, oxidizing agents.

ACT29GNR529/252807/090/813

SABS Regulatory Affairs and Consumer Protection

**Risk phases : R22**

**Safety phrases : S2,S24/25,S26,S45,S36/37/39**