

OXI - ACT

PERACETIC ACID- DESTAINER DISINFECTANT FOR LAUNDRY

DESCRIPTION

Oxi-Act is a paracetic acid sanitizer / detainer utilizing oxygen suitable for all types of industrial laundry machines. Oxi Act is an environmentally friendly sanitiser / disinfectant.

APPLICATIONS (Usage Areas).

Oxi Act is predominantly used in health care and hospitality laundry operations as an effective disinfectant and detainer in the wash process.

DIRECTIONS FOR USE

Add 2 to 5ml Oxi-Act per kg of Linen during in the main wash at temperature of between 45 - 70°C. This will effectively disinfect and SAFELY bleach the linen. Oxi Act is designed for use through GeoChem automatic dosing / dispensing equipment. Dosage may vary according to degree of soiling.

BENEFITS

Broad spectrum efficacy
High level of germicidal activity
Ambient applications
Suitable in hard and soft water
Safe on colours
Free rinsing
Economical in use

SAFETY PRECAUTIONS

Personal Protection:

Safety glasses, adequate ventilation, gloves, face protection and, if using significant quantities, full body protection against a possible explosion.

Stability:

Unstable - may explode on heating. May react violently with organic materials. Incompatible with strong oxidizing agents, acetic anhydride, alkenes, organics.

- Do not mix with other detergents
- Avoid direct contact with eyes and skin
- Wear impervious rubber gloves
- Do not ingest product
- **Keep out of the reach of children**

Toxicology

Toxic by inhalation, ingestion or if absorbed through skin. Caustic and corrosive at concentrations >10%; irritant at concentrations below 2%.

EMERGENCY TREATMENT

Skin contact: Flush immediately with soap and water, wash contaminated clothing before reuse. If irritation develops, seek medical advice.

Eye contact: Rinse immediately with plenty of water for 15 minutes with eyelids held wide open. Seek medical advice.

Inhalation: Move person to fresh air and seek medical advice.

Ingestion: Do not induce vomiting. Give 2 glasses of water to drink and seek immediate medical attention.

STORAGE

Within the original unopened packaging Oxi-Act has a shelf life of one year. Once dispensed use immediately.

Conditions to avoid:

Temperatures above 30C, direct sunlight and heat.

Incompatible materials:

Soaps, ammonia, chlorine, acids, bases and amines.

Store out of reach of children.

Registration Number:

ACT29GNR529/259737/080/734

SABS Regulatory Affairs and Consumer Protection

For detailed safety instructions, refer to our Material Safety Data Sheet. For any queries contact GeoChem on +27 31 705 2711 or email info@geochem.co.za

We believe the product referred to herein, will perform the functions for which they are intended, but do not, in any way guarantee or warrant that they will do so, as conditions of actual use are beyond our control. Under no circumstances shall we be liable for any consequential loss of profits arising from their use.